

Passend für: / Fits to Modell:**Mercedes M-Klasse (W166)****Baujahr: / Year of Manufacturing:****11/2011-****Art.-Nr.: / Item No.:****MBK390/395****Achtung!**

Achten Sie aus Sicherheitsgründen beim Befestigen der Konsole (beim Bohren und Schrauben) auf den Verlauf von vorhandenen, insbesondere nicht sichtbaren Kabelsträngen, Leitungen und anderen Komponenten, die sich im Montagebereich befinden!

Die Konsole und die darauf zu befestigenden Anbauteile sind so zu montieren, dass für die Fahrzeuginsassen keine Verletzungsgefahr (z. B. durch scharfe Kanten) entsteht.

**Attention!**

Due to safety reasons pay attention to the course of existing, also non-visible cables, wires and other components which are situated in the installation area!

Note: The console and the components are to be installed in such a way that for the passengers no dangers of injury (e.g. by sharp edges) develops.

**Abbildung 1:**

Handschuhfach öffnen, vorderes Blech in den Spalt der Verkleidung schieben, wie auf dem Bild zu sehen.

**Picture 1:**

Open the glovebox and put the front metal sheet into the gap of the cover as shown in the picture.

**Abbildung 2:**

Den Sitz der Konsole kontrollieren und mit der mitgelieferten Schraube an der markierten Stelle (s. Pfeil.) durch das Blech verschrauben.

**Picture 2:**

Check the fitting of the dashboard-console and screw the supplied screw at the marked position (s. arrow) through the metal sheet to fix the dashboard-console.


	Einbauanleitung Installation Manual
Passend für: / Fits to Modell:	Mercedes M-Klasse (W166)
Baujahr: / Year of Manufacturing:	11/2011-
Art.-Nr.: / Item No.:	MBK390/395



Abbildung 3:

**Handschuhfach schliessen.
Fertig eingebaute Konsole.**



Picture 3:

**Close the glovebox.
Build in dashboard-console.**